

ROUNDLINE Eco

The best comfort and economy

The electronic thermostat gives a temperature stability of $\pm 0,1^{\circ}\text{C}$ regardless of the outdoor temperature. When additional heat emerges in the room the heater shuts off completely before the temperature rises even $\pm 0,5^{\circ}\text{C}$ in the room. Roundline Eco has a smooth front. The end of the heater has a sinkage where the thermostat control, the power switch and the light emitting diode are placed. The light emitting diode indicates which program is chosen and that the heater is turned on.

*ACCESSORIES

Wireless control: Roundline Eco can be complemented with a small receiver (placed in the end of the heater) that communicates with a small Room unit. Several radio receivers can be connected to the same room unit. An extra thermostat detects additional heat in the room eg. heat from the sun. Already at $0,1^{\circ}\text{C}$ over the set temperature the thermostat starts to adjust the heaters, this saves energy. You are able to complement the radio receiver with Reco Master, which can control the heaters remotely by using a GSM dialer or a timer.

***Does not apply to Eco 2000W. Can't be remotely controlled.**

SERVICE OCH GARANTIER

Kontakta vår Kundtjänst om du har frågor angående Roundline.

Garantitid: 2 år från inköpsdatum.

Tego Kundtjänst tel: 0418 - 45 58 25

ROUNDLINE IS A SAFE RADIATOR

Roundline will never be hotter than 70°C on the surface (230V/400V). When normal operation (50% load, 230V/400V) the temperature of the surface is approx. 35°C . Overheating protection device: Do not cover the heater! The heater is equipped with an overheating protection device, which turns the heater off if the heater for some reason would become too hot. Roundline has no sharp corners or edges. The low temperature heater will not be hotter than 60°C on the surface and is usually placed in a children's cottage playhouse.

MAINTENANCE

The smooth front is easy to keep clean. Roundline is easy to swing out or detach when cleaning or restoring. Vacuum from underneath the radiator.

SERVICE AND WARRANTY

Any further questions, please contact:

Tego Customer Service Phone +46 418 45 58 25

Warranty: 2 years from the purchase date.

Watt	Length	Height	Volt	Order nr.	Order nr.
Standard temperature IP21 ▲					
400	638	200	230	E8511804	E8511864
			400	E8511805	
600	750	200	230	E8511806	E8511866
			400	E8511807	
800	974	200	230	E8511808	E8511868
			400	E8511809	
1000	1198	200	230	E8511810	E8511870
			400	E8511811	
1200	1422	200	230	E8511812	E8511872
			400	E8511813	
300	414	400	230	E8511824	E8511874
			400	E8511825	
600	638	400	230	E8511826	E8511876
			400	E8511827	
800	750	400	230	E8511828	E8511878
			400	E8511829	
1000	974	400	230	E8511830	E8511880
			400	E8511831	
1200	1198	400	230	E8511832	E8511882
			400	E8511833	
1500	1422	400	230	E8511834	E8511884
			400	E8511835	
2000	1758	400	230	E8511836	E8511886
			400	E8511837	
Low temperature IP21 ▲					
450	750	400	230	E8511854	
			400	E8511855	
600	1198	400	230	E8511856	
			400	E8511857	
750	1500	400	230	E8511858	
			400	E8511859	

Accessories*

Radiomottagare	E8511690
Rumstermostat	E8511691
Reco Master	E8511689

*Not the 2000W.